



Maintenance-free

## VRL1 volume flow limiter

that operates without an auxiliary power supply, for ventilation and air conditioning systems.

- Sizes DN 80 to DN 250.
- Flow velocities from 0.8 m/s, differential pressures from 30 Pa.
- Infinitely adjustable volume flows using scales.
- Hygienic design using microbe-resistant materials.
- Environmental Product Declaration according to ISO 14025 and EN 15804
- Options: Drilling templates, sliding sleeves, duct sleeves.

# VRL1 volume flow limiter

Overview: Limiter and optional accessories



**VRL1 volume flow limiters** are designed for insertion into circular ventilation ducts for supply air and exhaust air in ventilation and air conditioning systems. They are used to replace conventional dampers, eliminating the manual, often time-consuming adjustment and calibration of volume flows in the systems. → see pages 3 and 6

Preset volume flow set points are automatically kept constant, even when sections of the systems are connected or disconnected during operation.

If the volume flow set point of the VRL1 volume flow limiter is to be adjusted in the installed position from the outside and remain accessible, an opening can be made in the duct wall using the reusable **drilling template** and closed again using the **inspection cover**.

→ see page 7



**Sliding sleeves** are provided with the inspection opening for adjusting the volume flow set point of the VRL1 volume flow limiter. Sliding sleeves must be inserted in circular ventilation ducts on one side and equipped with a detachable plug-in connection on the other.

→ see page 7

The circular ventilation duct can be opened and the VRL1 volume flow limiter removed.

This also allows the circular ventilation duct to be cleaned and disinfected.



VRL1 volume flow limiters in **duct sleeves** can be accessed via plenum boxes of air diffusers in suspended ceilings, if ceilings cannot be opened for example.

VRL1 volume flow limiters in sliding sleeves can also be **adjusted by a motor**. Depending on which drive is selected, two set points or any intermediate values can be adjusted. → see page 8

Sufficiently large plenum boxes without damper flaps are suitable. If VRL1 volume flow limiters are

to be taken out of the duct sleeve, the perforated panels inside the plenum box must

be demountable or the plenum box must not contain any perforated panels. → see page 9




**SRC duct silencer**

→ see page 9

# VRL1 volume flow limiter

Description, sizes, technical data



- 1 Controller casing for duct insertion
- 2 Control system
- 3 Volume flow set point adjustment  
Screw head TX 8
- 4 Setting pointer and scale
- 5 Lip seal

Maintenance-free **VRL1 volume flow limiters** are mechanical controllers that operate without an auxiliary power supply to maintain volume flows in ventilation and air conditioning systems constant. They regulate volume flows with reference to preset set points and keep these constant.

VRL1 volume flow limiters can be used in any installation position in circular ventilation ducts; in spiral ducts for example.

The adjustment and control mechanism of the VRL1 volume flow limiters is enclosed and protected against contamination from the air flow. Furthermore, the lip seals on both sides position and fix the VRL1 volume flow limiter in the circular ventilation duct so that a complete enclosure is created overall.

The controller casing and damper blade are made from a special anti-static and microbe-resistant plastic. The smooth surfaces of the air-ducting components virtually eliminate soiling. VRL1 volume flow limiters therefore comply with maximum hygiene requirements.

- Sizes: DN 80 to DN 250
- Total volume flow range:  $V_{\min} = 13 \text{ m}^3/\text{h}$  to  $V_{\max} = 1060 \text{ m}^3/\text{h}$
- Differential pressure range: 30 Pa to 300 Pa  
⇒ see pages 4 and 5
- Interior temperature range: +10°C to +50°C


Delivery forms VRL1	Drilling template	Sliding sleeve		Duct sleeve	SRC duct silencer
		without drive	with drive		
factory-mounted in	-	x	x	x	-
to be installed on site with/in	x	x	-	x	x

The sliding sleeves and duct sleeves satisfy casing leak tightness class C according to DIN EN 1751

VRL1 volume flow limiters are adjusted at the factory to the entire volume flow ranges, starting with at least 1 : 7! The set point can be set continuously variably site using a rotary pointer on a scale with volume flow and velocity specifications between  $V_{\min}$  and  $V_{\max}$ , and then locked. The special control mechanism ensures a high degree of control accuracy with a deviation of approx.  $\pm 5 \%$  to  $\pm 10 \%$  throughout the entire range of application.

Where control deviations are specified as a percentage, the maximum adjustable volume flow set point is used as reference. Other deviations can occur in the lower range of application, especially with small sizes! Disrupted flows should be compensated for. ⇒ see page 6

Size DN	$V_{\min}$ [m <sup>3</sup> /h]	$V_{\max}$ [m <sup>3</sup> /h]	Ød [mm]	L [mm]	A <sub>A</sub> [m <sup>2</sup> ]
80	13	110	79	100	0,005
100	20	170	99	125	0,008
125	35	270	124	150	0,012
160	50	440	159	160	0,020
200	75	680	199	200	0,031
250	125	1060	249	250	0,049




## VRL1 volume flow limiters

- satisfy the **hygiene requirements** according to VDI 6022-1, VDI 3803-1, DIN 1946-4 and DIN EN 13779, SWKI VA104-01 and SWKI 99-3, ÖNORM H6020 and ÖNORM H6021.
- are **resistant to microbes**, and therefore **do not promote the growth of micro-organisms (fungi, bacteria)**. This reduces the risk of infection for people and also the necessary cleaning and disinfection work!
- are **resistant to cleaning agents and disinfectants** and are suitable for use in hospitals and similar facilities!
- with **environmental product declaration** according to ISO 14025 and EN 15804:  
EPD-WIL-20150038-ICA1-DE


# VRL1 volume flow limiter

Sound power level in the connecting duct (flow noise)


Size DN 80




Size DN 100



Size DN 125



Size DN 160




Nomenclature ⇒ see page 5


# VRL1 volume flow limiter

## Sound power level in the connecting duct (flow noise)

Size DN 200



Size DN 250



**Example:** ⇒ see page 4

Specified:	Size	DN 160
	Volume flow	$V = 100 \text{ m}^3/\text{h}$
	Flow velocity	$v_A = 1.4 \text{ m/s}$
	Static pressure drop	$\Delta p_s = 100 \text{ Pa}$
Result:	Flow noise	
	Sound power level	$L_{WA} = 41 \text{ dB(A)}$
	Attenuation (duct, room)	$\Delta L_{L,R} = 8 \text{ [dB]}$
	Sound pressure level	$L_{pA} = 33 \text{ dB(A)}$

- In the nomograms, the sound power level within the connecting duct is calculated as an A-weighted overall level  $L_{WA}$ .
- The sound power levels can be reduced by up to 24 dB using SRC duct silencers.
- Alternatively, the Wildeboer dimensioning software can be used as a design aid. ⇒ see page 9

This software also calculates the octave sound power level  $L_{W-Oct}$  for each size of VRL1 volume flow limiter and each operating point, also with additional SRC duct silencer.

### Note

Sound power levels  $L_{WA}$  are decisive for determining the sound energy introduced into the duct system and should always be used for the acoustic calculation, including when adding sound attenuators and ventilation ducts with deflections and branches.

Sound pressure levels  $L_p$  or  $L_{pA}$  are frequently specified instead of the sound power level  $L_{WA}$ . Their numerical values can be up to 10 dB lower, as the duct and room attenuation to be deducted from the sound power levels  $L_{WA}$  is generally pre-empted. This essential difference must be taken into consideration when purely comparing numerical values!

### Nomenclature

$V$	[m <sup>3</sup> /h]	Volume flow
$V_{min}$	[m <sup>3</sup> /h]	Minimum adjustable volume flow set point
$V_{max}$	[m <sup>3</sup> /h]	Maximum adjustable volume flow set point
$A_A$	[m <sup>2</sup> ]	Inflow cross-section
$v_A$	[m/s]	Flow velocity in $A_A$
$\Delta p_s$	[Pa]	Static pressure drop

$L_{WA}$	[dB(A)]	A-weighted sound power level
$L_{W-Oct}$	[dB]	Octave sound power level $L_{W-Oct} = L_{WA} + \Delta L$
$\Delta L$	[dB]	Relative sound power level to $L_{WA}$
$f$	[Hz]	Octave mid frequency
$L_p$	[dB]	Sound pressure level
$L_{pA}$	[dB(A)]	A-weighted sound pressure level
$\Delta L_{L,R}$	[dB]	Attenuation (ventilation duct, room)


# VRL1 volume flow limiter

## Installation instructions

To ensure the VRL1 volume flow limiter functions optimally in ventilation and air conditioning systems, the standard operating conditions must exist. It should be installed under largely undisrupted flow conditions. The example inflow and outflow lengths shown should particularly be observed at close flow disruption points (fire dampers, shut-off dampers, reductions, widenings, bends, branches, T-pieces, plenum boxes) as otherwise control deviations could result which may require the controller to be readjusted. A series of disruption points can be compensated for by longer inflow and outflow lengths.

### VRL1 volume flow limiter for installation in circular ventilation ducts:

- Prior to insertion in the circular ventilation ducts, the VRL1 volume flow limiters must be set on site to the required volume flow set point and locked! The volume flow set point must be set using the pointer (1) on the scale (2). The screw (3) must be tightened to lock the setting; screw head TX 8.
- The volume flow limiter must be inserted into the ventilation duct so that the specified air flow direction (4) corresponds to the air flow direction in the ventilation duct.
- Make sure that the ducts have the necessary concentricity and that the installation is tension-free. The VRL1 volume flow limiters must be inserted against the direction of air flow (4) so that the lip seals (5) are in contact with the duct walls – as shown in the figure. In doing so, only press on the lateral feed guides of the controller casing! The damper blade move freely at all times.
- Two labels are affixed to the VRL1 volume flow limiter. The purpose of one (6) is to explain the handling. The other (7) identifies the installation location, the direction of flow and the set volume flow set point; both must be observed and should be affixed to the outside of the circular ventilation duct.



### Please note!

VRL1 volume flow limiters are factory-adjusted control devices. Manual interventions in the mechanism are not permitted!

When a high volume flow set point is set, the damper blade must not be closed manually!

The permissible range of application is limited to 300 Pa differential pressure and 6 m/s inflow velocity. In addition, the size-related load limits must be adhered to. This protects the limiters from mechanical overload.

The inspection covers may only be removed to adjust the volume flow set points when the system is switched off!

### Installation close to flow disruption points




Figure 1: downstream of a fire damper




Figure 2: downstream of a reduction




Figure 3: downstream of a widening




Figure 4: downstream of a bend




Figure 5: downstream of a T-piece





Figure 6: installation combined with a plenum box

### Range of application and load limits




# VRL1 volume flow limiter

Optional accessories: Drilling templates and sliding sleeves with inspection cover

## Using the drilling templates


Openings made on site in circular ventilation ducts, which ensure that the VRL1 volume flow limiters remain accessible and can be easily adjusted in the installed position, should be prepared using **drilling templates**. The openings manufactured in this way are closed afterwards with inspection covers made of flexible plastic.

- The drilling template (1) specifies the positions of the holes to be drilled in the circular ventilation duct (2) for the inspection cover (4) and the fixing screw (3). A step-by-step description of the procedure and all details is provided on the drilling template.
- Once the drilling positions have been marked, the template is removed and can be re-used. The holes for the fixing screw (3.3 mm) and inspection cover (BK\_ 35 mm / BG\_ 44 mm) are then introduced and deburred as required.
- VRL1 volume flow limiters can then be inserted into the circular ventilation duct with an accurate fit and secured with the fixing screw (3). If this has not already been done, the volume flow set point must be set and locked.
  - ⇒ see page 6
- The inspection cover must then be inserted!
- A **subsequent adjustment of the volume flow set point** can be carried out via the inspection opening by removing the inspection cover.
  - ⇒ see operating instructions



1 Drilling template      3 Fixing screw  
2 Circular ventilation duct, on site      4 Inspection cover

**VRL1 volume flow limiters inserted into sliding sleeves** must be installed between circular ventilation ducts. Sliding sleeves are made of galvanised sheet steel and open the circular ventilation duct completely to allow the VRL1 volume flow limiter to be completely removed. The inspection cover which is made of flexible plastic can also be opened and the volume flow set point adjusted from the outside.



1 Sliding sleeve      5 Lip seal for insertion  
2 Direction of air flow      6 Lip seal for repositioning  
3 Marking sticker      7 Inspection cover  
4 Circular ventilation duct, on site      8 Plug-in connector

- When installing the sliding sleeve (1), the direction of air flow (2) marked on the VRL1 volume flow limiter or indicated by the marking sticker (3) must be observed.
- The tapered part of the sliding sleeve is inserted into one end of the circular ventilation duct (4) according to L2; the continuation of the circular ventilation duct (4) is connected at the plug-in connector (8). The locations of the various lip seals (5) and (6) must be observed during installation – as shown in the figure.
- For the circular ventilation duct to be opened using the sliding sleeve, it is essential to observe the spacing L4 between the ends of the circular ventilation ducts. This ensures that the insertion length L3 of the tapered part of the sliding sleeve in the circular ventilation duct is guaranteed and therefore that the VRL1 volume flow limiter can be removed.
- If this has not already been done, the volume flow set point must be set and locked. ⇒ see page 6
- Afterwards, the inspection cover (7) must be inserted!
- A **subsequent adjustment of the volume flow set point** can be carried out via the inspection opening by removing the inspection cover. ⇒ see operating instructions
- The **“Removal of the VRL1 volume flow limiter from the sliding sleeve”** is carried out in reverse order to the installation procedure. The sliding sleeve must be disconnected from the plug-in connector in order to open the circular ventilation duct. The tapered part must be inserted into the circular ventilation duct. The fixing screw (opposite the volume flow set point adjustment) must be undone in order to be able to take the VRL1 volume flow limiter out of the sliding sleeve. For re-installation, observe the installation requirements. ⇒ see page 6
- **Electric adjustment of the volume flow set point:** ⇒ see page 8

Size DN	L1 [mm]	L2 [mm]	L3 [mm]	L4 [mm]
80	432	40	160	352
100	472	40	185	392
125	517	40	210	437
160	547	40	230	467
200	632	40	270	552
250	807	60	340	687

# VRL1 volume flow limiter

Optional accessories: Sliding sleeves with electric adjusting drives

## Electric adjustment of VRL1 volume flow limiters inserted into sliding sleeves.

VRL1 volume flow limiters in sliding sleeves can be supplied with electric adjusting drives M1, M2 or M3 that set volume flow set points in different ways.

- The adjusting actuators M1 or M2 facilitate two-point operation (single-wire control). Depending on the electrical control, the actuators run against one of the two limit stops and therefore switch between two volume flow set points.

This can be extended to include three-point operation using an additional 0 circuit arrangement (two-wire control). When actuated in this way, the actuator remains in its current position and the VRL1 volume flow limiter adjusts the corresponding set point.

- The adjusting actuator M3 facilitates controlled and continuous adjustment of the volume flow set point. The actuation is carried out with an adjusting voltage  $Y = 0 / 2 \dots 10$  V DC, in which case the operating range of the actuator only starts at 2 V. The actuator moves between the two limit stops in the position specified by the actuating signal, which means that specific intermediate values within the volume flow range can be set.


A synchronisation operation starts and the actuator moves to a home position ( $Y = 0$  V, „left“ limit stop) the first time the power supply is switched on and after every voltage interruption; the actuator then moves to the position specified by the actuating signal. The purpose of the checkback voltage  $U = 2 \dots 10$  V DC is to provide an electric display of the volume flow set point setting and serve as a subsequent actuating signal for other actuators.

- The motorised adjusting actuators are overload-proof, do not require a limit switch and stop automatically at the limit stops.
- In the as-delivered condition, the manually-adjustable limit stops of the actuators are set to the minimum and maximum volume flow set point specified for each nominal size. The two volume flow set points (M1, M2) or the two limit values of the volume flow range (M3) can be adjusted manually on site by changing the positions of the corresponding limit stops. ⇒ see operating instructions
- In the event of a power failure, the actuators remain in their current position and the VRL1 volume flow limiters regulate the corresponding set point.
- The gear can be disengaged with the aid of a magnet (component of the adjusting actuators) in order to adjust it manually. The gear remains disengaged while the magnet remains in the position marked by the magnet symbol.
- Even when supplemented by a motor, the VRL1 volume flow limiter can be easily removed from the sliding sleeve.  
⇒ see operating instructions


Adjusting drive	M1	M2	M3
Supply voltage	230 V AC	24 V AC/DC	24 V AC/DC
Function area	85 V to 265 V	19.2 V to 28.8 V	19.2 V to 28.8 V
Torque	2 Nm	2 Nm	2 Nm
Runtime for 90°	75 s	75 s	75 s
Connecting duct	3 VA	1 VA	1 VA
Power consumption	1.5 W	0.5 W	0.5 W
Degree of protection	IP 54	IP 54	IP 54
Connection cable approx. 1 m long	0.75 mm <sup>2</sup> 3-wire	0.75 mm <sup>2</sup> 2-wire	0.75 mm <sup>2</sup> 2-wire
Ambient temperature	-30°C to +50°C	-30°C to +50°C	-30°C to +50°C

### Adjusting drive M1 / M2



Single-wire control



Two-wire control



### Adjusting drive M3



Size DN	L5 [mm]
80	66
100	63
125	63
160	58
200	55
250	52

- 1 Sliding sleeve
- 2 Motor-driven set point adjustment

Download at [www.wildeboer.de](http://www.wildeboer.de):

- Dimensioning software
- Hygiene certificate
- Hygiene instructions for disinfection
- Operating instructions



# VRL1 volume flow limiter

Optional accessories: Duct sleeves for plenum boxes and SRC duct silencers

**VRL1 volume flow limiters inserted into duct sleeves** are designed for plenum boxes of air diffusers in ceilings. Duct sleeves are made of galvanized sheet steel and have a DN size connection for the circular ventilation duct on one side, and an enlarged connection sleeve on the other side for fitting onto the connecting piece of the plenum box. This allows the VRL1 volume flow limiter to be removed and the volume flow set point to be adjusted.


A sufficiently large plenum box with lateral connecting pieces and without damper flaps is required for this. It should not contain any perforated panels, or, if it does, they must be demountable.

The application is particularly suitable for closed ceilings that cannot be accessed.

Duct sleeves (1) are supplied with the VRL1 volume flow limiter installed in the supply air flow direction (2).

- Before the duct sleeve is installed, the VRL1 volume flow limiter must be removed, adjusted and reinserted in the duct sleeve, taking the direction of flow into account (supply air or exhaust air). The nominal size, direction of flow and set volume flow set point must be noted on the marking sticker (3).  
→ see page 6
- The duct sleeve must be connected to the circular ventilation duct with the connection diameter  $\varnothing$  DN and to the plenum box (4) with the larger connecting sleeve  $\varnothing$  DN1.
- The ceiling diffuser (5) must be removed **in order to subsequently adjust the volume flow**. This allows the VRL1 volume flow limiter to be accessed via the plenum box and removed from the duct sleeve. The lock must be released in order to carry out the adjustment. The volume flow set point can then be readjusted and locked. For re-installation, observe the installation requirements. → see page 6

**Note:** The VRL1 volume flow limiters in duct sleeves and ceiling diffusers with plenum boxes must be coordinated in terms of dimensioning and design. In doing so, their acoustic characteristics must be taken into account!




- 1 Duct sleeve
- 2 Flow direction
- 3 Marking sticker
- 4 Plenum box
- 5 Ceiling diffuser
- 6 Ceiling

Size DN	Size DN1	L1 [mm]	L2 [mm]	L3 [mm]	L4 [mm]
80	100	286	40	41	245
100	125	335	40	41	295
125	150	381	40	41	340
160	180	405	40	41	365
200	224	509	40	64	465
250	280	628	60	62	585

## SRC duct silencer

SRC duct silencers facilitate the reduction of flow noise in the circular ventilation duct.



Maximum reduction of flow noise

Size DN	Outer $\varnothing$ [mm]	L1 [mm]	L [mm]	
			600	900
80	200	40	-22 dB	-
100	200	40	-22 dB	-25 dB
125	225	40	-22 dB	-25 dB
160	260	40	-21 dB	-24 dB
200	300	40	-19 dB	-24 dB
250	355	40	-18 dB	-22 dB

# VRL1 volume flow limiter


Order data: VRL1 volume flow limiter, options, delivery by instalments

## VRL1 volume flow limiter

### with options

- Sliding sleeve ⇒ see pages 2 and 7
- Duct sleeve ⇒ see pages 2 and 9

Size DN 80 / 100 / 125 / 160 / 200 / 250  
⇒ see page 3



Adjusting drives exclusively for sliding sleeve

- M1 230 V AC two-point/three-point drive
  - M2 24 V AC/DC two-point/three-point drive
  - M3 24 V AC/DC continuous drive
- ⇒ see pages 2 and 8

Ordering example: VRL1 - 01 - S - 100 - M2

The volume flow set point must be adjusted on site at the VRL1 volume flow limiter. ⇒ see page 6

VRL1 volume flow limiters with adjusting drive set the volume flow set point electrically. ⇒ see page 8

## Delivery by instalments without VRL1 VRL1 - 00 - -

- Drilling template ⇒ see pages 2, 7 and 10


for sizes DN 80 bis DN 125

- with 1 inspection cover BK1
- with 10 inspection covers BK10

for sizes DN 160 bis DN 250

- with 1 inspection cover BG1
- with 10 inspection covers BG10

- Sliding sleeve ⇒ see pages 2, 7 and 10 S
- Duct sleeve ⇒ see pages 2, 9 and 10 R



Size of sliding sleeve / duct sleeve  
DN 80 / 100 / 125 / 160 / 200 / 250  
⇒ see pages 7 and 9

Ordering example: VRL1 - 00 - S - 100


## Delivery of SRC by instalments

Size ⇒ see page 9

DN 80 / 100 / 125 / 160 / 200 / 250

Length

- 600
- 900 (from DN 100)



Ordering example: SRC - 125 - 600

**Delivery of drilling templates by instalments** for creation of an inspection opening in on site circular ventilation ducts.



### BK1 and BG1

### Scope of delivery

- 1 drilling template, re-usable
- 1 inspection cover
- 1 fixing screw

### BK10 and BG10

- 1 drilling template, re-usable
- 10 inspection covers
- 10 fixing screws

**Delivery of sliding sleeves by instalments** for on site insertion of a VRL1 volume flow limiter. Assembly instructions are enclosed with the sliding sleeve and must be observed.



### Scope of delivery

- 1 sliding sleeve
- 1 plug-in connector
- 1 lip seal for insertion
- 2 lip seals for repositioning
- 1 inspection cover
- 1 fixing screw
- 1 assembly instructions

**Delivery of duct sleeves by instalments** for on site insertion of VRL1 volume flow limiters. Assembly instructions are enclosed with the duct sleeve and must be observed.



### Scope of delivery

- 1 duct sleeve
- 1 lip seal for insertion
- 1 assembly instructions

# VRL1 volume flow limiter

## Specification text

Maintenance-free volume flow limiter for regulation of constant volume flows in ventilation and air conditioning systems. Mechanically self-actuating, operating without an auxiliary power supply, for position-independent insertion into circular ventilation ducts. Controller casing and centrally supported damper blade made of special anti-static, microbe-resistant plastic with smooth surfaces and air-ducting components that are collectively resistant to soiling. The adjustment and control mechanism is fully enclosed and protected against contamination from the air flow. Lip seals are provided on both sides in order to fix the position in the ventilation duct and create a complete enclosure.

Adjusted at the factory and infinitely adjustable and lockable on site with a rotary pointer on a scale with specifications on the volume flow and flow velocity. The volume flow is kept constant by a high-precision special control mechanism with variable pressures from 30 Pa to 300 Pa and a deviation of around  $\pm 10\%$  to  $\pm 10\%$  with reference to the maximum volume flow set point.

### Options:

- Volume flow limiter with drilling template and inspection cover for installation in circular ventilation ducts and subsequent manual adjustment of the volume flow set point in the installed position.
- Volume flow limiter installed in a sliding sleeve made of galvanized sheet steel for straightforward removal of the volume flow limiter and simple manual adjustment of volume flow set point in the installed position via the corresponding inspection cover.
- Volume flow limiter installed in a sliding sleeve made of galvanized sheet steel, with 230 V AC or 24 V AC/DC two-point/three-point drive or 24 V AC/DC continuous drive for adjustment of the volume flow set point.
- Volume flow limiter with duct sleeve made of galvanized sheet steel with enlarged diameter. For direct installation on plenum boxes which ensure that the volume flow limiter can be accessed at all times.

With conformity certificate as proof of compliance with the hygiene requirements according to VDI 6022-1, VDI 3803-1, DIN 1946-4, DIN EN 13779, SWKI VA104-01, SWKI 99-3, ÖNORM H6020 and ÖNORM H6021. With environmental product declaration according to ISO 14025 and EN 15804.

### ..... Units

Volume flow:	.....	m <sup>3</sup> /h	
Pressure drop:	.....	Pa	
Maximum sound power level flow noise:	.....	dB(A)	
including SRC duct silencer			
Manufacturer:		WILDEBOER	
Type:		VRL1	
Size:	.....		
		deliver:	.....
		install:	.....

Duct silencer for reduction of flow noise in the circular ventilation duct. Casing made of galvanized sheet steel with mineral wool fillings.

### ..... Units


Type:		SRC	
Diameter DN:	.....		
Length:	.....		
		deliver:	.....
		install:	.....

Select texts not highlighted in bold as required!

INNOVATIVE • PRACTICAL • ECONOMICAL

**WILDEBOER®**

Factory - Administration  
Telephone: +49 (0)4951 - 950 - 0  
Fax: +49 (0)4951 - 950 - 27120  
E-mail: [info@wildeboer.de](mailto:info@wildeboer.de)  
Internet: [www.wildeboer.eu](http://www.wildeboer.eu)



**WILDEBOER®**

Utrecht office  
Telephone: +31 30 767 0150  
E-mail: [info@utrecht.wildeboer.eu](mailto:info@utrecht.wildeboer.eu)

**WILDEBOER®**

Leipzig office  
Telephone: +49 (0)34444 - 310 - 0  
Fax: +49 (0)4951 - 950 - 27298  
E-mail: [info@leipzig.wildeboer.de](mailto:info@leipzig.wildeboer.de)

**WILDEBOER®**

Ulm office  
Telephone: +49 (0)7392 - 9692 - 0  
Fax: +49 (0)4951 - 950 - 27299  
E-mail: [info@ulm.wildeboer.de](mailto:info@ulm.wildeboer.de)

TAKE ADVANTAGE OF OUR STRENGTHS!

**WILDEBOER®**

COMPONENTS FOR VENTILATION + AIR CONDITIONING

air distribution fire protection noise protection

building control systems